



Duraplas Flat Pack Growbed Stand



Instructions



Layout the Duraplas GB800 pack on the ground as per this image.



Position the leg support pieces as per this image.



Your will need your own cordless drill and the screw bits provided in the kit. A Tape Measure and Marker are also required



Using two screws per end (positioned diagonally), fasten the leg cross members as per this image. Repeat this step for each leg profile.



Mark the centre of each leg unit cross member using the short scrap provided in the kit. The distance between the centre support and the side supports is 220mm. Mark each side support as well.



Screw the three support lengths in place as per image
(Two screws per joint).



Screw the top/side rails in place using two screws positioned diagonally and into the top of each leg post. The overhang on the ends is 400mm.



Screw the top frame ends into place as per this image.



Ensure the legs are upright and the whole frame is square before screwing 1m lengths of bracing into position as per this image.



Position the Grow Bed into frame and screw the tub lip to the frame by spacing the small screws provided evenly around the GB800 lip.



Your new Duraplas GB800 Grow Bed is now ready to put into service.

